





akyga AK-CH-12 - user manual



















# Short description of the product

The Akyga AK-CH-12 USB charger is used to deliver power to a mobile device via household socket. The 18 W power adapter is compatible with all 5 - 12 V / 1.5 - 3 A devices with USB plug. A set of protectors OVP, OTP, OPP, SCP, OCP and the soft start technology provides safe and stable work of both power supply and powered device.

The product is adapted to supply voltage in the range of 220-240 V, 50/60 Hz.

The power consumption of powering nootebook can not exceed the power supply nominal current.

The product is compatible with the applicable national and European requirements.

### What is in the box?

- AK-CH-12 power supply

## Symbols explanation:



There is a particular danger connected with service.



There is a risk of losing health or life (e.g. by electic shock).



Important tips and information.



The CE standard description on the product is the manufacturer's declaration that the marked product meets the requirements of the directive so-called The "New Approach" of the European Union (EU). For security and certification (CE) reasons, the device can not be rebuild or change in any way. In the reason of using the power supply for other purposes than those described, the product may be demaged. The incorrect use may also cause hazard such as short-circuits, burns, electric shocks, etc. Read the users manual carefully and keep it for later use. The product could be share to third partie only with the user manual included.





Product accordance with the EU directive 2002/96/EC. The symbol of the crossed out basket placed on the product means that the marked product can not be disposed of with other household waste. After use, the product must be return to collection point for used electical and electronic equipment or to the seller. Appropriate segregation of rubbish for subsequent processing, recovery or descrution contributes to avoiding negative effects on the environment and health, and also allows the recovery of raw materials from which the product is made.



The RoHS mark on the product is the manufacturer's declaration that the marked product meets ROHS the requirements of the EU Restriction of Hazardous Substances (2002/95/EC) directive, which aims to reduce the amount of hazardous substances penetrating into the environment from electrical and electronic waste.

# akyga<sup>®</sup> AK-CH-12 - user manual





### **Safety Precautions**

A

WARNING! Product heats up during operation. To reduce the risk of burns or overheating the power supply, do not place it in restricted ventilation area. Also, do not allow the working power supply to touch soft surface such as pillows, blankets or clothing. The power supply meets the limits on the surface temperatures available to the user, as defined in the International Standard for Safety of Information Technology Equipment (IEC 60950).



Connecting smartphone or other device whose demanded power is greather than power of the power supply, can cause battery failure or even damage (burn) of power supply.



An electrostatic discharge occurs when two object touch each other, for example, an electric charge that occurs when user touch metal door handle after walking on a carpet . Discharging electrostatic charges from fingers or other electrostatic conductors can damage electronic components. To avoid damaging the computer, abstain from touching electrical outlets, wires and electronic circuits. The user's contact with electronic components should be kept to a minimum.



The manufacturer of the product is not responsible for damage or insults caused in effect of disobey the safety instructions and informations contained in these user manual.



- Keep the product and the packaging out of range of children and animals. The package includes a foil that child could choke while playing.
- It is forbidden to apply the mechanical load to the product strong shocks, impacts, dropping or crushing may cause its damage.
- The product operation in adverse conditions is not allowed. Adverse conditions are primarily: exposure to direct sunlight, high or very low ambient temperatures, strong vibrations, high humidity, surrounds of gases, dusts or flammable and aggressive liquids.
- If the product has been damaged, does not work properly or has been stored for a long period of time in bad or unfavorable conditions, safe operation of the device is not possible. It is essential to stop using the product and to protect it against re-use for security purposes.
- Take account of the user manual for other devices connected to the USB power adapter.
- Product and power cord should not be touched with moist or wet hands under no circumstances.
- Short-circuiting the current connection is prohibited.
- Connection of USB power adapter to electricity is made by plugging the adapter to corresponding socket in your vehicle.
- Before connecting the adapter to the socket, make sure that the voltage specified on the power supply matches voltage supplied to the cigarette lighter socket.
- Adapter should be disconnect from power socket if it is not in use for a long time.
- In case of any doubts regarding operation, safety or connection of the product, please contact the manufacturer or a qualified specialist for this purpose.
- All maintenance, adjustment and repair work on the product may only be carried out by a qualified person in a specialist facility.



### Removing the most common problems

Problem	Cause	Solution
A smartphone or other device connected to an electrical outlet via power supply does not work	No mains voltage	<ul> <li>Check the correct connection of the power supply to the mains socket</li> <li>Check the mains fuses</li> </ul>
	The power adapter is overloaded	Disconnect the power adapter from the laptop, check the correctness of the current parameters
	There is a suspicion of a product defect	Stop using and contact the seller
A smartphone or other device connected to an electrical outlet via power adapter does not charge the battery or displays a message about the non-genuine charger	The power adapter does not correspond to the current parameters	<ul> <li>Disconnect the power adapter from smartphone or other device and check if current parameters are correct</li> <li>Contact with seller</li> </ul>

# **Preparing the Power Supply for Use:**

- 1. Connect power adapter to the electrical socket.
- Connect the power adapter to the USB cable.
- 3. Connect the USB cable with the smartphone or other device.
- 4. The charging process will start automatically.

### Cleaning the power supply



Disconect the power supply from the electrical socket and connected devices before cleaning.



- Use soft and antistatic cloth for cleaning the power supply.
- Do not use abrasive or chemical cleaners.

# **Technical specfication**

Product code:	AK-CH-12
Supply voltage:	220-240 V, 50/60 Hz
Output voltage:	5 - 12 V
Output amperage:	1.5 - 3 A
USB-C output voltage:	5 V / 3 A, 9 V / 2 A, 12 V / 1.5 A
USB-A output voltage:	5 V / 3 A, 9 V / 2 A, 12 V / 1.5 A
Maximum power:	18 W
Efficiency:	>80%
OVP (over voltage protection):	Yes
OCP (over current protection):	Yes
OPP (overpower protection):	Yes
OTP (over temperaturre protection):	Yes
SCP (short circuit protection):	Yes
Power inlet:	CEE 7/16 (Europlug)
Output connector:	USB-A, USB-C
Compilance with standards:	CE, FCC, RoHS
EAN code:	5901720137111

# **USB Power Adapter**

Product manufacturer: